




Note: Refer to the MC2KW Owner's Manual page 4 for additional connection information.


**Connection Legend:**

- Data Cable\* - — Digital Signal Cable - —
- Sensor/Keypad Cable - — Interconnect Cable - —
- Power Control Cable\* - — Ground Wire - —
- Audio Signal Cable - — AC Power Cords - —
- Video Signal Cable - — Loudspeaker Cable - —
- RF Signal Cable - —

\* 2 conductor shielded with 1/8 inch stereo mini phone plug on each end.




MC2KW Output Module (Right Channel)




Connect to second MC2KW Output Module (Left Channel) Power Control In

MC2KW Power Module (A)



MC2KW Power Module (B)



Note: Refer to the MC2KW Owner's Manual page XX for additional connection information.

**Connection Legend:**

- Data Cable\* - — Digital Signal Cable - —
- Sensor/Keypad Cable - — RS232 Cable - —
- Power Control Cable\* - — Ground Wire - —
- Audio Signal Cable - — AC Power Cords - —
- Video Signal Cable - — Loudspeaker Cable - —
- RF Signal Cable - —

\* 2 conductor shielded with 1/8 inch stereo mini phone plug on each end.

