


Note: Refer to the MC303 Owner's Manual page 8 for additional connection information.

Connection Legend:

- Data Cable* - — Digital Signal Cable - —
 - Sensor/Keypad Cable - — RS232 Cable - —
 - Power Control Cable* - — Ground Wire - —
 - Audio Signal Cable - — AC Power Cords - —
 - Video Signal Cable - — Loudspeaker Cable - —
 - RF Signal Cable - —
- * 2 conductor shielded with 1/8 inch stereo mini phone plug on each end.




Note: Refer to the MC303 Owner's Manual page 9 for additional connection information.

Connection Legend:


- Data Cable* - — Digital Signal Cable - —
- Sensor/Keypad Cable - — RS232 Cable - —
- Power Control Cable* - — Ground Wire - —
- Audio Signal Cable - — AC Power Cords - —
- Video Signal Cable - — Loudspeaker Cable - —
- RF Signal Cable - —

* 2 conductor shielded with 1/8 inch stereo mini phone plug on each end.


Left Front Loudspeaker





Center Front Loudspeaker




Right Front Loudspeaker




A/V Control Center



Left Surround Loudspeaker



Left and Right Channel Surround Power Amplifier (Partial)



Right Surround Loudspeaker

